




Parts Manual

Mfg. No: 14B932-0026-F1


Model Components	Page
Air Cleaner.	4
Alternator, Electric Starter, Ignition.	6
Blower Housing, Cover/Guards, Flywheel.	8
Camshaft, Crankshaft, Cylinder, Piston/Rings/Connecting Rod, Warning Label.	10
Carburetor, Carburetor Overhaul Kit.	12
Controls, Governor Spring, Thermostat.	16
Cylinder Head, Gasket Set-Valve, Valves.	18
Exhaust System.	20
Fuel Supply, Lubrication.	22
Gasket Set-Engine, Sump.	24
Replacement Engine - US & Canada.	26

Not For
Reproduction




Air Cleaner

REF NO	PART NO	QTY	DESCRIPTION
11	796478		TUBE, Breather
163	691894		GASKET, Air Cleaner -(Air Cleaner)
265	690798		CLAMP, Casing
267	691044		SCREW -(Casing Clamp)
347	795333		SWITCH, Rocker
445	795066		FILTER, A/C Cartridge
497	691044		SCREW -(Stopswitch Bracket)
627	796702		BRACKET, Stopswitch
875	796492		BASE, Air Cleaner
967	796254		FILTER, Pre Cleaner
968	796493		COVER, Air Cleaner
971	690349		SCREW -(Air Cleaner Base to Carburetor/Throttle Body)



Alternator, Electric Starter, Ignition

REF NO	PART NO	QTY	DESCRIPTION
309	799241		MOTOR, Starter
333A	595959		ARMATURE, Magneto
334	793454		SCREW -(Magneto Armature)
337	692051		PLUG, Spark -(Resistor)
347	795333		SWITCH, Rocker
356J	592156		WIRE, Stop
365	793458		SCREW -(Carburetor/Throttle Body)
383	19576S		WRENCH, Spark Plug
474	794103		ALTERNATOR
621	692310		SWITCH, Stop
627	796702		BRACKET, Stopswitch
635A	692076		BOOT, Spark Plug
697	691127		SCREW -(Starter Motor) (Drive Cap)
742	93941		RETAINER, E Ring
851	493880S		TERMINAL, Spark Plug
853A	695897		ADAPTER, Wire
910	796498		STUD -(Alternator) -Used Before Code Date 16082900
910A	596414		STUD -(Alternator) -Used After Code Date 16082800
937	799420		SPLINE, Starter
1119	794100		SCREW -(Alternator)
1119A	596420		SCREW -(Alternator)
1153	691186		WASHER -(Support Bracket)
1212	799269		STUD -(Blower Housing) -Used Before Code Date 12031900
1212	591164		STUD -(Blower Housing) -Used After Code Date 12031800
1212B	799263		STUD -(Blower Housing) (Used With Alternator Only) -Used Before Code Date 12031900
1212B	591166		STUD -(Blower Housing) (Used With Alternator Only) -Used After Code Date 12031800



Blower Housing, Cover/Guards, Flywheel

REF NO	PART NO	QTY	DESCRIPTION
23B	591399		FLYWHEEL -(Cast Iron)
24	796335		KEY, Flywheel -(Steel)
37A	596417		GUARD, Flywheel
58	697316		ROPE, Starter -(Cut To Required Length)
60	281434S		GRIP, Starter Rope
75	691736		WASHER -(Flywheel)
78	793480		SCREW -(Flywheel Guard)
304A	596419		HOUSING, Blower -Used After Code Date 16120400
304A	591171		HOUSING, Blower -Used Before Code Date 16120500
332	690662		NUT -(Flywheel)
363	19069		PULLER, Flywheel
455A	591400		CUP, Flywheel
608	796497		STARTER, Rewind
668	797373		SPACER
668A	797383		SPACER
925	796531		COVER, Linkage
949	799474		GUARD, Debris Screen
1005	799265		FAN, Flywheel
1006	799264		RETAINER, Fan
1212	591164		STUD -(Blower Housing) -Used After Code Date 12031800
1212	799269		STUD -(Blower Housing) -Used Before Code Date 12031900
1212A	799268		STUD -(Blower Housing) -Used Before Code Date 12031900
1212A	591165		STUD -(Blower Housing) -Used After Code Date 12031800
1212B	799263		STUD -(Blower Housing) (Used With Alternator Only) -Used Before Code Date 12031900
1212B	591166		STUD -(Blower Housing) (Used With Alternator Only) -Used After Code Date 12031800
1335	793481		NUT -(Blower Housing)

1319 WARNING LABEL

**WARNING**

Read and follow Operating Instructions before running engine.

Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.

Engines emit carbon monoxide. **DO NOT** run in enclosed area.

Exhaust area temperature may exceed 150°F. Do not touch hot parts.








REQUIRED when replacing parts with warning labels affixed.

1036 EMISSIONS LABEL

1319A WARNING LABEL




REQUIRED when replacing parts with warning labels affixed.




Camshaft, Crankshaft, Cylinder, Piston/Rings/Connecting Rod, Warning Label

REF NO	PART NO	QTY	DESCRIPTION
1	596413		CYLINDER ASSEMBLY -Used After Code Date 16082800
1	799278		CYLINDER ASSEMBLY -Used Before Code Date 16082900
3	299819S		SEAL, Oil -(Magneto Side)
16	591414		CRANKSHAFT
24	796335		KEY, Flywheel -(Steel)
25	799271		PISTON ASSEMBLY -(.020 Oversize)
25	799270		PISTON ASSEMBLY -(Standard)
26	799273		SET, Ring -(.020 Oversize)
26	799272		SET, Ring -(Standard)
27	691588		LOCK, Piston Pin
28	799274		PIN, Piston
29	796470		ROD, Connecting
32	691664		SCREW -(Connecting Rod)
32A	695759		SCREW -(Connecting Rod)
43	593912		SLINGER, Governor/Oil
46	694039		CAMSHAFT
404	690272		WASHER -(Governor Crank)
615	690340		RETAINER, Governor Shaft
616	798327		CRANK, Governor
718	690959		PIN, Locating
741	797521		GEAR, Timing
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1263	697124		REED, Breather
1264	793453		SCREW -(Breather Reed)
1319	794467		LABEL, Warning
1319A	797669		LABEL, Warning
1375	799493		COVER, Breather Reed
1376	794451		SCREW -(Breather Reed Cover)
1430A	799494		GASKET, Breather/Reed



Carburetor, Carburetor Overhaul Kit


REF NO	PART NO	QTY	DESCRIPTION
51	796596		GASKET, Intake
51A	590398		GASKET, Intake
95	691636	1	SCREW -(Throttle Valve)
98	797156	1	KIT, Idle Speed
104	797622		PIN, Float Hinge
108	597553	1	VALVE, Choke
117A	590440	1	JET, Main -(Standard)(-Used After Code Date 18113000)
117	498977	1	JET, Main -(Standard)(-Used Before Code Date 18120100)
118A	797575	1	JET, Main -(High Altitude)(-Used After Code Date 18113000)
118	692677	1	JET, Main -(High Altitude)(-Used Before Code Date 18120100)
121	796612	1	KIT, Carburetor Overhaul
122	796595	1	SPACER, Carburetor
125A	84002386	1	CARBURETOR -Used After Code Date 18113000
125	799479	1	CARBURETOR -Used Before Code Date 18120100
127	694468	2	PLUG, Welch -(Bowl Vent)
130A	597437	1	PLATE, Throttle
131	597552	1	KIT, Throttle Shaft
133A	797626	1	FLOAT, Carburetor -Used After Code Date 18113000
133	398187	1	FLOAT, Carburetor -Used Before Code Date 18120100
134A	799177	1	KIT, Needle/Seat -Used After Code Date 18113000
134	398188	1	KIT, Needle/Seat -Used Before Code Date 18120100
137A	797625	1	GASKET, Float Bowl -Used After Code Date 18113000
137	796610	1	GASKET, Float Bowl -Used Before Code Date 18120100
141	597541	1	KIT, Choke Shaft
163	691894	1	GASKET, Air Cleaner -(Air Cleaner)
187	791766	1	LINE, Fuel
202	796657	1	LINK, Mechanical Governor
216	796485	1	LINK, Choke
217	799179	1	SPRING, Choke Return
231	691636	1	SCREW -(Throttle Valve) (Choke Valve)
276A	797632	1	WASHER, Sealing -Used After Code Date 18113000
276	271716	1	WASHER, Sealing -Used Before Code Date 18120100
365	793458	2	SCREW -(Carburetor/Throttle Body)
601	691024	2	CLAMP, Casing
623	793628	1	SEAL, O-Ring -(Carburetor Spacer)



Carburetor, Carburetor Overhaul Kit


REF NO	PART NO	QTY	DESCRIPTION
633	797629	2	SEAL, Choke/Throttle Shaft
951	597537	1	LEVER, Choke
951A	597538	1	LEVER, Choke
975A	797631	1	BOWL, Float -Used After Code Date 18113000
975	796611	1	BOWL, Float -Used Before Code Date 18120100

Not For Reproduction




Controls, Governor Spring, Thermostat

REF NO	PART NO	QTY	DESCRIPTION
202	796657		LINK, Mechanical Governor
209	796484		SPRING, Governor
216	796485		LINK, Choke
222	796482		BRACKET, Control -(Manual Friction, Remote, & Fixed Speed Control)
227	796487		LEVER, Governor Control
265	690798		CLAMP, Casing
267	691044		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
291	799483		THERMOSTAT
505	793515		NUT -(Governor Control Lever)
562	793514		BOLT -(Governor Lever)
621	692310		SWITCH, Stop
745	793491		SCREW -(Brake)
883	793497		GASKET, Exhaust
922	692135		SPRING, Brake
923	796635		BRAKE




Cylinder Head, Gasket Set-Valve, Valves

REF NO	PART NO	QTY	DESCRIPTION
5	592175		HEAD, Cylinder
7A	799275		GASKET, Cylinder Head
13	799277		SCREW -(Cylinder Head)
33	499642		VALVE, Exhaust
34	795443		VALVE, Intake
35	691304		SPRING, Valve -(Intake)
36	691304		SPRING, Valve -(Exhaust)
40	692194		RETAINER, Valve
45	690977		TAPPET, Valve
51	796596		GASKET, Intake
163	691894		GASKET, Air Cleaner -(Air Cleaner)
192	796631		ADJUSTER, Rocker Arm
238	691300		CAP, Valve
337	692051		PLUG, Spark -(Resistor)
383	19576S		WRENCH, Spark Plug
623	793628		SEAL, O-Ring -(Carburetor Spacer)
635A	692076		BOOT, Spark Plug
718	690959		PIN, Locating
830	796472		STUD, Rocker Arm -(Rocker Arm)
868	597316		SEAL, Valve
883	793497		GASKET, Exhaust
886	799492		KIT, Cylinder Head/Plate Gasket
914	794451		SCREW -(Rocker Cover)
993	796473		GASKET, Cylinder Head Plate
1022	796480		GASKET, Rocker Cover
1023	796479		COVER, Rocker
1026	796481		ROD, Push
1029	691230		ARM, Rocker
1034	691343		GUIDE, Push Rod
1095	592174		GASKET SET, Valve




Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
81	691740		LOCK, Muffler Screw
300B	799259		MUFFLER -Used Before Code Date 16112100
300C	596409		MUFFLER -Used After Code Date 16112000
613	799260		SCREW -(Muffler) -Used Before Code Date 16112100
613A	596410		SCREW -(Muffler) -Used After Code Date 16112000
676A	799187		DEFLECTOR, Muffler
832B	596014		GUARD, Muffler
836	597516		SCREW -(Muffler Guard)
837	799261		SPACER -(Muffler)
883	793497		GASKET, Exhaust



Fuel Supply, Lubrication

REF NO	PART NO	QTY	DESCRIPTION
187	791766		LINE, Fuel -(Cut To Required Length)
187A	796491		LINE, Fuel -(Formed Hose)
240	298090S		FILTER, Fuel
523	796503		DIPSTICK
524	692296		SEAL, O-Ring -(Dipstick Tube)
525	796502		TUBE, Dipstick
601	791850		CLAMP, Hose
670	793485		SPACER, Fuel Tank
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	796501		DIPSTICK/TUBE ASSEMBLY
957	799585		CAP, Fuel Tank
957A	692046		CAP, Fuel Tank
957C	796577		CAP, Fuel Tank
958	698183		VALVE, Fuel Shut Off
972	590949		TANK, Fuel
1059	793471		KIT, Screw/Washer



Gasket Set-Engine, Sump

REF NO	PART NO	QTY	DESCRIPTION
3	299819S		SEAL, Oil -(Magneto Side)
4B	596013		SUMP, Engine
7A	799275		GASKET, Cylinder Head
12	692232		GASKET, Crankcase
15	691680		PLUG, Oil Drain -(Square Socket)
17	798538		BEARING, Ball
20	399781S		SEAL, Oil -(PTO Side)
22	691092		SCREW -(Crankcase Cover/Sump)
51	796596		GASKET, Intake
163	691894		GASKET, Air Cleaner -(Air Cleaner)
358	592173		GASKET SET, Engine
524	692296		SEAL, O-Ring -(Dipstick Tube)
623	793628		SEAL, O-Ring -(Carburetor Spacer)
718	690959		PIN, Locating
737	692511		SCREW -(Oil Filter Adapter)
750	691147		SCREW -(Oil Pump Cover)
842	691031		SEAL, O-Ring -(Dipstick Tube)
868	795440		SEAL, Valve
883	793497		GASKET, Exhaust
943	692514		SEAL, O-Ring -(Oil Pump Cover)
965	692507		COVER, Oil Pump
988	692515		GASKET, Oil Adapter
993	796473		GASKET, Cylinder Head Plate
1022	796480		GASKET, Rocker Cover
1024	692508		PUMP, Oil
1027	795990		FILTER, Oil
1028	796522		ADAPTER, Oil Filter
1055	796524		TUBE, Oil Pump
1430A	799494		GASKET, Breather/Reed

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	14B9320027F1	1	Replacement Engine
	-----		Top No-Load Speed: 3300

Not For Reproduction

